


Shock Interactions in Nonequilibrium Hypersonic Flows



Joanna M Austin, Andrew Swantek, Andrew Kniseley

University of Illinois at Urbana-Champaign

Debbie Levin

The Pennsylvania State University

AFOSR Aerothermodynamics and Turbulence Portfolio Review

Arlington, VA, 15-18 July 2013

FA 9550-11-1-0129



Experiments with “Tunable” Freestream


- Double cone/wedge flows are a sensitive model problem for thermochemical modeling validation.
- Significant work both experimentally and computationally has been performed (Olejniczak *et al.* (1999); Wright *et al.* (2000); Nompelis *et al.* (2003, 2005, 2010)).
- *State-of-the-art* simulations and experiments show poor agreement in high enthalpy ($\geq 5\text{MJ/kg}$) air flows, in spite of good agreement at lower enthalpies and in N_2
- Outstanding questions: freestream characterization, flow steadiness. thermochemistry.

A novel method of gas acceleration that minimizes free stream dissociation while producing a broad range of hypervelocity flows.

GOAL: Turn on/off the thermochemistry:

- 1) *N_2 to air while maintaining Mach and Ho*
- 2) Low enthalpy to high.

Quantify the response of viscous and inviscid flow features



Previously:

- Heat transfer & single-shot schlieren data for eight test cases (varying freestream O_2 and H_2O).
- Flow field establishment and possible unsteadiness examined experimentally.
 - Inviscid and viscous time scales measured using high speed schlieren and time-resolved heat transfer.
 - Comparisons with simulations (D. Levin) in progress; outstanding issues (challenges slide).

Currently:


- Which features of the flow are thermochemically activated & when? (Leading to why?!)
 - Direct measurements of chemical species and temperatures combined with flow feature visualization.



Hypervelocity Expansion Tube (HET)

- 152 mm ID, 9.14m length impulse facility
- Mach Numbers from 3-7.5
- Stagnation enthalpies from 2-9 MJ/kg
- Test times from 100 μ s to 500 μ s

Dufrene, Sharma, Austin 2007



- Diagnostic capabilities
 - Pressure Measurements
 - Schlieren (single frame & high speed)
 - Heat transfer measurements
 - Coaxial thermocouple
 - Platinum thin film gauges
 - Emission spectroscopy
 - Pressure Sensitive Paint



Test conditions and models

- Air can be replaced with N_2 and yields nearly the same freestream conditions.
- Two different model geometries are used.

| Run Condition | M | h_0 MJ/kg | T, K | P, kPa | ρ , kg/m ³ | u, km/s | Re/m *10 ⁻⁶ |
|---------------|------|----------------|------|-----------|-------------------------------|------------|---------------------------|
| M7_8 | 7.14 | 8.0 | 710 | 0.78 | 0.0038 | 3.81 | 0.44 |
| M5_4 | 5.12 | 4.2 | 676 | 8.2 | 0.042 | 2.67 | 3.47 |
| M4_3.6 | 3.95 | 3.6 | 862 | 19 | 0.077 | 2.33 | 4.73 |
| M7_2.2 | 7.11 | 2.1 | 191 | 0.39 | 0.0071 | 1.97 | 1.10 |


25°-55° cone

– RTO studies


30°-55° wedge

– Scale model of Davis and Sturtevant's wedge





30-55 Double Wedge L=2", b=4"



25-55 Double Cone $d_1=0.984"$, $d_2=2.5"$




Sample cases showing differences between Air/N₂



Mean Surface Heat Transfer – 8MJ/kg


Mach 7

(M7_8)



High Speed Schlieren: N2 and Air





Double Wedge
M7_8
Top: Air
Bottom: N₂
100,000 fps
7 fps playback
1 μ s exposure
200 μ s test time



- Nitrogen exhibits a larger standoff distance = 2.29 mm
- Consequences for shock impingement, which occurs further downstream for air.
- Nitrogen shows more emission



Triple point establishment process: moving upstream



“Tuning” freestream from N₂ to Air

Mach 7, $H_o = 8\text{MJ/kg}$

Percentages indicate the freestream oxygen percentage compared to atmospheric air.
Compositions below.


| Mixture | Freestream | | Post Shock (Equilibrium) | | | | | T, K |
|----------|----------------|----------------|--------------------------|----------|----------------|----------|----------|------|
| | N ₂ | O ₂ | N ₂ | N | O ₂ | O | NO | |
| Nitrogen | 1.000 | 0.000 | 9.330E-1 | 6.697E-2 | - | - | - | 5178 |
| 30% | 0.926 | 0.074 | 8.404E-1 | 2.329E-2 | 3.250E-4 | 1.286E-1 | 7.343E-3 | 4754 |
| 50% | 0.883 | 0.117 | 7.821E-1 | 8.755E-3 | 1.978E-3 | 1.924E-1 | 1.473E-2 | 4425 |
| 80% | 0.825 | 0.175 | 7.057E-1 | 2.025E-3 | 1.474E-2 | 2.480E-1 | 2.949E-2 | 3990 |
| Air | 0.790 | 0.210 | 6.659E-1 | 1.082E-3 | 3.152E-2 | 2.639E-1 | 3.751E-2 | 3902 |

| Mixture | f_{N_2} | f_{O_2} |
|----------|-----------|-----------|
| Nitrogen | 3.46 | - |
| 30% | 1.79 | 99.5 |
| 50% | 1.48 | 98.1 |
| 80% | 2.18 | 90.4 |
| Air | 2.82 | 82.7 |

Dissociation Fraction (%) =
[dissociated molecules]/[initial concentration]




Sample post-shock quantities vs. freestream O_2



Lead shock location vs O₂ content

Edge tracking extracts shock surfaces from high speed images.

Percentages indicate the freestream oxygen percentage compared to atmospheric air. Compositions below.




| Mixture | Freestream | | Post Shock | | | | | T, K |
|----------|----------------|----------------|----------------|----------|----------------|----------|----------|------|
| | N ₂ | O ₂ | N ₂ | N | O ₂ | O | NO | |
| Nitrogen | 1.000 | 0.000 | 9.330E-1 | 6.697E-2 | - | - | - | 5178 |
| 30% | 0.926 | 0.074 | 8.404E-1 | 2.329E-2 | 3.250E-4 | 1.286E-1 | 7.343E-3 | 4754 |
| 50% | 0.883 | 0.117 | 7.821E-1 | 8.755E-3 | 1.978E-3 | 1.924E-1 | 1.473E-2 | 4425 |
| 80% | 0.825 | 0.175 | 7.057E-1 | 2.025E-3 | 1.474E-2 | 2.480E-1 | 2.949E-2 | 3990 |
| Air | 0.790 | 0.210 | 6.659E-1 | 1.082E-3 | 3.152E-2 | 2.639E-1 | 3.751E-2 | 3902 |

High-Speed Chemiluminescence

Note: images taken during establishment process

N2



2 μ s,
100kHz




High-Speed Chemiluminescence

Note: images taken during establishment process

80%


O₂



High-Speed Chemiluminescence


Note: images taken during establishment process

AIR



Schlieren & Chemiluminescence overlay


N2



Note: single shot images after flow established;
Separate experiments; false color chemiluminescence

Schlieren & Chemiluminescence overlay


80%
O₂



Note: single shot images after flow established;
Separate experiments; false color chemiluminescence

Schlieren & Chemiluminescence overlay


AIR



Note: single shot images after flow established;
Separate experiments; false color chemiluminescence

Quantifying response to increasing freestream O_2

170 μ s




N2

AIR



- Reflect observable differences in shock configurations and luminescence
- Activity behind reattachment shock affects L_{sep} (Davis & Sturtevant, N2)
- Activity behind separation shock
 - appears to initiate near boundary

130 μ s



Spectroscopic Setup

- Post bow shock NO emission spectroscopy.
 - NO γ band in the UV (220-255nm) is interrogated.
 - $f/4$ 270M SPEX spectrometer: 43 μm slit, 1200 g/mm grating, 1.56 Å resolution.
 - PI-Max 512 ICCD camera.
 - 110 μs exposure time in highest enthalpy condition on the double wedge.
- Spectrometer calibration.
 - Fe hollow cathode used for wavelength.
 - Hamamatsu UV-VIS Deuterium lamp used for intensity.




- Optic fiber is used to transmit light.
 - Non-negligible losses through the fiber, therefore calibration of the fiber is performed.
- Guide plate is fabricated via wire EDM for spatial alignment of the optics
 - Four holes at 2 mm spacing are drilled 6.1 mm above the nominal triple point location




Temperature fitting

- Two codes are used for temperature fitting.
 - LIFBASE:
 - 5 vibrational levels.
 - 80 rotational levels.
 - In house code (Sharma 2010):
 - 20 vibrational levels
 - 250 rotational levels.
- Simulation wavelengths interpolated to match experimental data.
- Residual minimized to obtain vibrational temperature fit.






AIR

Shot 1197, 4mm position, in house simulation, $T=7280\text{K}$.





Verification behind normal shock



Calculation: 128 species model based on Adamovich
Sharma, Austin, Glumac, Massa, AIAA J, 2010






Temperature Profiles



4 sampling positions
(kept relative to shock location)



Comparisons of HET spectral NO data with line-by-line spectral simulations




Assuming a single internal
temperature

Simulations by Prof Levin

Significantly improved fit to
data with **both rotational
and vibrational
temperatures included.**

Conclusions

- Data available: Heat transfer and single shot schlieren (AVT 205)
Experimental viscous and inviscid establishment times
- Quantification of link between thermochemical activity and gas dynamic flow features
Schlieren imaging overlaid with
 - chemiluminescence
(global, qualitative)
 - spectroscopic temperature measurements
(point, quantitative)as a function of freestream O₂ content.
- Transition in shock configurations and temperature measurements identified at 80% O₂.
- In air, NO vibrational temperatures well-captured by in-house spectral code (Sharma, Austin, Glumac, Massa)
- Additional spectral fits in collaboration with D. Levin in progress



Outstanding Challenges

- Installation and operation of Cordin camera for higher resolution imaging of separation zone – flow establishment and unsteadiness
- Additional off-centerline data (3D effects?)
- Spatial resolution of spectroscopic measurements



Acknowledgements

We gratefully acknowledge:

extensive collaborations with Prof Levin (PSU).

Prof. Hans Hornung, Drs. Eric Marineau, Simon Sanderson, Adam Rasheed, Ivett Leyva, Bahram Valiferdowsi (Caltech)

William Flaherty, Dr Manu Sharma, Prof Nick Glumac (Illinois)

FA9550-11-1-0129; Dr John Schmisser

